


# HEXPANDER pass-through connections to Acousti-Phonic



signal through-pins on Acousti-Phonic board (ground pins not shown)

