


MIDI Volume Pot
 Lets you instantly change the MIDI controller's volume level without taking your hand off your guitar.

Program Up/Down Switch
 Lets you instantly change the MIDI controller to the next patch without taking your hand off your guitar.


Quick Switch
 Plugged into the Hexpander, it lets you instantly select MIDI, piezo, or both at the same time; without adjusting volume controls!



PK-0440-00 Hexpander Kit

- PE-0440-00 Hexpander MIDI Adapter
- PE-0181-00 Hexpander Volume Pot

- PE-0111-00 Quick Switch with Wiring Harness
- PE-0180-00 Program Up/Down Switch



Mid/Dark Tone Switch
 Lets you select from two piezo tone settings with a push-push switch in the piezo volume knob.

Quick Switch
 Plugged into the Acousti-Phonic, it lets you instantly select magnetic, piezo, or both blended together; without adjusting volume controls!

PK-0240-00 Acousti-Phonic Kit

- PE-0240-00 Acousti-Phonic Preamp
- PE-0111-00 Quick Switch with Wiring Harness
- PE-0206-00 Volume Pot with Mid/Dark Tone Switch